



# NIKO




## 黑洞 Neostar

压块安装范围扩展  
Clamping Zone Extension




该图仅代表檩条横跨长边/短边的压块安装，以上数字表示压块边缘距离边框的距离，单位：mm  
This load graph present when the purlin cross the long side/short side, number means the distance between the edge of clamp to the frame. Unit:mm




该图仅代表檩条横跨长边/短边的压块安装，以上数字表示压块边缘距离边框的距离，单位：mm  
This load graph present when the purlin cross the long side/short side, number means the distance between the edge of clamp to the frame. Unit:mm

# NIKO



慧星  
Comet


压块安装范围扩展  
Clamping Zone Extension



**MAH-72Mw 2278\*1134**


+5400/-2400 Pa  
 +2400/-2400 Pa  
 +1000/-1000 Pa  
 No Clamping

该图仅代表檩条横跨长边/短边的压块安装，以上数字表示压块边缘距离边框的距离，单位：mm  
 This load graph present when the purlin cross the long side/short side, number means the distance between the edge of clamp to the frame. Unit:mm




该图仅代表檩条横跨长边/短边的压块安装，以上数字表示压块边缘距离边框的距离，单位：mm  
This load graph present when the purlin cross the long side/short side, number means the distance between the edge of clamp to the frame. Unit:mm

# NIKO



恒星  
Stellar

压块安装范围扩展  
Clamping Zone Extension



该图仅代表檩条横跨长边/短边的压块安装，以上数字表示压块边缘距离边框的距离，单位：mm  
This load graph present when the purlin cross the long side/short side, number means the distance between the edge of clamp to the frame. Unit:mm